

ChimneyCapDesign.com



TO SAVE SHIPPING COST, THIS CAP MIGHT BE SHIPPED WITH UNMOUNTED HOOD. ASSEMBLE IT ACCORDINGLY WITH THIS PICTURE. YOU WILL NEED 1/2" WRENCH OR PLIERS.

This product comes fully assembled. No drilling or gluing. Just insert base of the cap into the flue and tight friction fit will hold this cap securely.



SkyRider Cap (SR) installation